




## Quick Setup Guide



Technical Helpline – 01543 506218

“Sensitivity” – range setting from 1m to 15m

“Time” - ON time after motion is sensed, 6secs to 45min.



### Installation

Install the lamp in to a standard 2D fitting following the lamp installation guide. Turn on the mains power to the lamp and leave the power on, the lamp will then automatically turn on and off as it detects movement.

### Walk Test Mode

Set the “TIME” adjuster to minimum to enter the walk test mode. The lamp will turn on for 3seconds when motion is detected and then turn off. Adjust the “SENSITIVITY” to achieve the desired range then set the “TIME” to the desired lamp on period.

### Light Level Sensor

When there is sufficient ambient light the lamp will not turn on even when movement is detected. In Walk Test Mode and on the 10% DIM version this sensor is ignored.

### 10% Dim Version

If you have the 10% DIM version when the mains is applied to the lamp it will turn on at 10% brightness and then switch to 100% brightness when movement is detected. The light level sensor is ignored on this version.